

---

---

# APPLICATION INSTRUCTIONS

---

---

## RECOMMENDED AMOUNT OF FLUID PER FABRIC CONTENT

❖ **100% Polyester**  
16 to 20 grams

❖ **50/50 Blends**  
14 to 18 grams

❖ **100% Cotton**  
13 to 16 grams

Below are the suggested application steps for applying the DTG Pretreat fluid on different fabric content. Print & Wash Tests are recommended for all types of garments to ensure maximum color brightness and washfastness.

### STEP #1:

Apply the Pretreat



### STEP #2:

Cure the Pretreat



### STEP #3:

Print the Garment



### STEP #4:

Cure the Ink



## HELPFUL TIPS FOR USING DTG PRETREAT:

- Use a hand-held spray bottle that provides you a good even mist spray. Spray the side of a cardboard box to see if it applies large drops.
- Measure the amount of each spray by weighing a cup on a postal scale, zero the scale, spray into the cup 10 times and re-weigh the cup. Divide the total grams by 10 to determine the # of grams every time you squeeze the trigger.
- Curing of the pretreat may vary depending on the garment, but it is recommended between 20 to 30 seconds or until the steam from the heat press stops.
- Perform a Print & Wash Test on all new garments before going into production. Track your results using a log.

---

---

For additional information, please contact:



**DIGITAL MARKETING  
SOLUTIONS**

Digital Marketing Solutions

509 S. Chickasaw Trail, #108 Orlando, FL 32825

E: [info@dtgpretreat.com](mailto:info@dtgpretreat.com)

W: [www.dtgpretreat.com](http://www.dtgpretreat.com)